



JK Ultimate Trackbar Instructions

1. With Jeep on level ground remove factory trackbar and hardware
2. Using the suggested length chart below, set all joints. (Note that on the double adjustable trackbars you must equally thread out and in each joint end. Torque the jam nuts to 180ft lbs of torque. Check the jam nuts and hardware after every wheeling trip and/or after 500 miles.

Suggested lengths:

Front

2.5" Lift 32 9/16"

3.5" Lift 32 5/8"

4.5" Lift 32 11/16"

5.5" Lift 32 7/8"

Rear w/Bracket

2.5" Lift 39 3/4"

3.5" Lift 39 3/4"

4.5" Lift 39 13/16"

5.5" Lift 40"

Warranty:

Center aluminum section is lifetime warrantied for failure, including bending, cracking, or breaking. Should any of these failures occur please send the center section to RPMSTEERING for replacement. (Shipping and handling additional).

Disclaimer:

Customer assumes full responsibility for use, installation and routine maintenance. RPM Steering is not responsible for damage as a result of improper installation, use or maintenance.