



AIR MATTRESS

(2018-2024+ WRANGLER JL - 4 DOOR)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Air Mattress
(1) Storage Bag

TOOLS REQUIRED

N/A



Fold down the vehicle rear seats. Un-fold the air mattress, ensuring the wider section of the mattress is towards the front of the vehicle.

Remove the power cable from the pump assembly, and route the cable towards the vehicle 12V outlet. Plug in the outlet and power the vehicle on. Turn the knob to power the pump on to fill the mattress. Fill the mattress until firm, do not over-fill.

To deflate, remove the plug along the rear of the mattress.

Clean the mattress using water, soap, and a cloth.

Installation is now complete.