



LOCKING ALUMINUM FUEL FILLER DOOR COVER

(2018-2025+ WRANGLER JL - EXCLUDING DIESEL MODEL)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) Fuel Door Assembly

TOOLS REQUIRED

10mm Socket
Ratchet
Flathead Screwdriver
Plastic Pry Tool

SKU # J240539

STEP 1



Remove the small plastic cover on the LH side cargo area panel, and remove the (1) 10mm tail light bolt. Once removed, pull to tail light to remove the assembly from the body, unplug the harness and set aside.

STEP 2



Through the tail light hole, use a long pry tool/flathead screwdriver to dislodge the mounting clips retaining the trim to the vehicle body. Remove the fuel cap, then remove the trim bezel.

Note: The lower retainers are the most accessible, once the lower retainers are dislodged, the trim can be manipulated to dislodge the uppers during removal.



STEP 3

Press the new fuel door to the vehicle, ensuring all retainers are firmly clipped to the vehicle body. Re-install the fuel cap and attach the tether to the fuel door housing.



STEP 4

Re-install the tail light to the vehicle reusing the original (1) 10mm bolt.

Installation is now complete.