

ALL WEATHER COVER

(2020-2021 GLADIATOR JT)

INSTALLATION INSTRUCTIONS

CONTENTS

(1) All Weather Cover

TOOLS REQUIRED

Adjustable Wrench Exterior Cleaner (Optional)





STEP 1

Clean the vehicle using automotive grade soap and water. Ensure vehicle is dry before continuing. Remove vehicle antenna using an adjustable wrench.



STEP 2

Lay the cover out to find the (2) straps. Unclip (2) buckles on the straps located under the cover. Locate front of cover - look for sticker that points front.

The arrow will point forward away from vehicle when cover is installed.





Drape cover over vehicle. Pull all the way over vehicle.



Once fully fitted, using the (2) straps, buckle the straps together on each side.

Installation is now complete.