

CUSTOM MOLDED MUD GUARDS

(2018-2023+ WRANGLER JL - EXCLUDING RUBICON)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Front Mud Guard
- (1) RH Front Mud Guard
- (1) LH Rear Mud Guard
- (1) RH Rear Mud Guard
- (16) Pop Rivets

TOOLS REQUIRED

Phillips Head Screwdriver Drill & 1/4" Drill Bit Trim Panel Removal Tool 1/4" Plastic Rivet Gun 8mm Socket & Ratchet





Begin by using a trim panel removal tool, remove the (2) lower push clips securing the back portion of the front fender liner in place.

**Note: These clips will be reused in a later step.




Remove the (2) plastic rivets located above by using a small screw driver and pushing the center of the rivet through. Then, fully remove the rivets from the fender flare.





Install the mud guard to the vehicle using the (2) plastic push clips from Step 1. Then using a 1/4" rivet gun and (2) plastic rivets, carefully rivet the side of the mud guard to the factory fender flare.



Using a drill & 1/4" drill bit, drill the additional hole into the factory fender liner. Then using a rivet gun and (1) plastic rivet, rivet the inner section of the mud guard to the fender liner.

^{**}Note: It may be necessary to turn the front wheels to achive space for drilling.





STEP 5

Repeat steps 1-5 for the opposite side.

Front installation is now complete.

See steps 6-10 for the rear mud guards.



STEP 6 (REAR)

Locate and remove the (1) 8mm screw securing the rear fender liner in place.

^{**}Note: Hardware will be reused in next step.





STEP 7

Using the (1) 8mm screw from the previous step, install the rear mud guard to the vehicle.

**Note: Be careful not to over tighten this screw.



STEP 8

Carefully press the mud guard against the rear bumper. Using a drill & 1/4" drill bit, drill the (3) holes from the mud guard into the rear bumper.





Using a 1/4" rivet gun and (3) supplied plastic rivets, rivet the mud guard to the rear bumper.



Repeat steps 6-10 for the opposite side.

Installation is now complete.