



FIXED LOWER CONTROL ARMS FOR 1.5-3” LIFTS

(2018-2022 WRANGLER JL)

INSTALLATION INSTRUCTIONS

CONTENTS

- (1) LH Control Arm w/ Zerk Fitting
- (1) RH Control Arm w/ Zerk Fitting
- (2) M8x1.25 x 20mm Flange Bolt
- (2) M8x1.25 Flange Nuts

TOOLS REQUIRED

- 13mm Socket/Wrench
- 15mm Socket/Wrench
- 21mm Socket/Wrench
- 24mm Socket/Wrench
- Ratchet/Breaker Bar
- Jack & Jack Stands
- Pry Bar


SKU # J164362-JL

STEP 1




Lift and support the vehicle using a jack and jack stands. Locate and remove (1) 15mm nut from the brake line bracket secured to the lower control arm. Allow brake line bracket to hang away from the control arm.

STEP 2



Locate and remove the (2) 21mm bolts from the lower control arm. Hold the nut in place with a 24mm wrench while loosening the bolt.



STEP 3

Install the new lower control arm into the vehicle reusing the original hardware. Do not fully tighten at this time.


Note: Aligning the lower control arm to the axle/frame may require using a floor jack/pry bar.



STEP 4


Secure the brake line bracket to the vehicle using (1) M8x1.25 x 20mm flange bolt and (1) M8x1.25 flange nut. Tighten until secure.

STEP 5



Lower the vehicle to the ground, tighten each control arm bolt to the OEM torque specification of 103 ft. lbs. + 145 degrees.

STEP 6



Repeat steps 1-6 to the opposite side of the vehicle.

Installation is now complete.