

LED HEADLIGHTS

(2014-2021 TUNDRA)

INSTALLATION INSTRUCTIONS


CONTENTS

(1) LH Headlight Assembly
(1) RH Headlight Assembly
(1) DRL Harness
(2) Turn Signal Adapters
(1) Dielectric Grease Packet

TOOLS REQUIRED


10mm Socket
Ratchet
Panel Removal Tool

STEP 1



Open the vehicle hood. Remove the small cover on the top of the grille using a pry tool. Unplug the grille electrical connector.

STEP 2




Remove (4) 10mm screws and (2) plastic push clips from the vehicle grille. Slightly lift, then pull the grille away from the vehicle and set aside.



STEP 3

Remove (2) plastic push clips from the painted panel below the headlight assembly. Then, pull the painted trim panel away from the vehicle fender to dislodge the retaining clips. Set the panel aside.



STEP 4

Remove (2) 10mm screws and (1) 10mm bolt from the headlight assembly. Then, begin to remove the headlight housing from the vehicle.

STEP 5



Unplug the electrical connectors from the back of the headlight assembly. Set the headlight assembly aside.


STEP 6



Route the included DRL harness from the vehicle fuse box to each headlight mounting location. Fit the fuse tap end of the harness into **Fuse IGN 10A**. Route the harness out of the fuse box.

Note: Notching the fuse box lid may be necessary to ensure the lid closes properly.

STEP 7



Plug the new headlight into the vehicle wiring harnesses. Plug the DRL harness into the headlight assembly.

Note: OEM Halogen Headlight vehicles will plug directly into the headlight assembly. Vehicles with OEM LED Headlights will require the LED adapter harness TU43268.

STEP 8



Turn Signal Adapter Harnesses: Depending on the vehicle wiring configuration, using the included turn signal adapter harnesses may be necessary. Take note to the OEM vehicle wiring harness wires into the connector in relation to the headlight harness.

STEP 9



Secure the headlight into the vehicle reusing the original hardware.

STEP 10



Re-install the vehicle body panels to the vehicle reusing the original hardware following steps 1-3 in reverse order.

Installation is now complete.